Datasheet Roller Shutter Z-Wave RSH-202-Z-01

Grenton Roller Shutter Z-Wave module allows for the control of blinds or roller shutter drives (e.g. external blinds, internal blinds, curtains, awnings), enables the connection of 2 digital inputs to the system, and supports the connection of one digital 1-Wire temperature sensor.



1. Parameters - ZWAVE ROLLER SHUTTER

Features:		
State	Output state: 0 - no movement, 1 - moving upwards, 2 - moving downwards, 3 - blocked	
Position	Percentage value of the shutter opening: 0% - fully closed, 100% - fully open	
LamelPosition	Roller shutter lamel position: 90 - fully closed, 0 - fully open	
LamelMoveTime	The time in milliseconds it takes to fully open / close the lamel	
MechanicalOffset	The time of compensation for start of the drive	
BlindsUpMoveTime	The time in milliseconds it takes to fully open the blind	
BlindsDownMoveTime	The time in milliseconds it takes to fully close the blind	
ReversePosition	The function for inverting position range (0-100% for 100-0%) : 0 - No, 1 - Yes	
Methods:		
Up	Roller shutter up	
Down	Roller shutter down	
Etart	Roller shutter up if the preceding motion was down or roller shutter down if the preceding	
Stall	motion was up	
Stop	STOP if moving	
Hold	Hold with direction change	
HoldUp	Hold always up	
HoldDown	Hold always down	
SetPosition	Shutter opening percentage setting: 0% - fully closed, 100% - fully open	
SetLamelPosition	Sets the position of the slats	
SetLamelMovetime	Sets the cycle time of the shutter	
SetMechanicalOffset	Sets the time of compensation for start of the drive	
SetBlindsUpMaxTime	Sets the shutter opening time	
SetBlindsDownMaxTime	Sets the shutter closing time	
SetRollerBlocked	Enables / disables the ability to control the roller shutter	
LamelStart	Changes the position of the slats by 45°	
Events:		
OnChange	Result from a change in the state of any of the outputs	
OnUp	Occurs when changing the Stop state to the Up state	
OnDown	Occurs when changing the Stop state to the Down state	
OnStart	Occurs when Start is requested	
OnStop	Occurs when Stop is requested	
OnLamelClosed	Occurs when the slats are closed (value 90°)	
OnLamelOpen	Occurs when the slats are opened (value 0°)	
OnPositionChange	Occurs when the roller shutter position has changed	
OnLamelPositionChange	Occurs when the position of the slats has changed	

2. Parameters - ZWAVE DIN

Features:		
HoldDelay	Time in milliseconds after which, when pressing and holding a button, the OnHold event oc- curs	
HoldInterval	Cyclical interval in milliseconds after which, when pressing and holding a button, the OnHo event occurs	
Value	Returns input state as 0 or 1	
Methods:		
SetHoldDelay	Sets HoldDelay value	
SetHoldInterval	Sets HoldInterval value	
Events:		
OnChange	Occurs when a change in the input state takes place (regardless of the value)	
OnSwitchOn	Occurs when the high state is set at input	
OnSwitchOff	Occurs when the low state is set at input	
OnShortPress	Occurs after pressing the button for 500-2000ms	
OnLongPress	Occurs after pressing the button for at least 2000ms	
OnHold	Occurs for the first time after HoldDelay time and then cyclically every HoldInterval value	
OnClick	Occurs after pressing the button for less than 500ms	

Parameters - ZWAVE 1-WIRE SENSOR

Features:		
Value	Input value	
MinValue	Minimum value of the Value characteristic after exceeding which the OnOutOfRange event is generated	
MaxValue	Maximum value of the Value characteristic after exceeding which the OnOutOfRange event is generated	
Status	Sensor status: 0 - disconnected; 1 - connected	
Events:		
OnChange	Event resulting from changing input state	
OnRaise	Event resulting from exceeding the upper threshold of hysteresis	
OnLower	Event resulting from exceeding the lower threshold of hysteresis	
OnOutOfRange	Event resulting from exceeding any range	
OnInRange	Event occurring when setting a value which is lower than the maximum value or higher than the minimum value	
OnConnect	Event resulting from connection with sensor	
OnDisconnect	Event resulting from disconnection with sensor	

4. Parameters - ZWAVE CONFIG

reatures:		
Register	Register (parameter) number	
Value	Register (parameter) value	
NodelD	Module's number (node) in the Z-Wave network	
Pappad	Returns information about communication with module: 0 - communication with the module	
Danneu	is not blocked, 1 - blocked communication with the module (module banned)	
FailCount	The number of failed communication attempts with the Z-Wave module	
Repeaters	Number of devices intermediating communication between the CLUZ and a given module	
RepeatersList	List of devices (NodeID) intermediating in communication between CLUZ and the module	
Standalone	Setting the internal connection between the device's inputs and outputs	
Methods:		
Set	Sets the value of the register (parameter)	
Get	Gets the value of a given register (parameter)	
SetDefault	Sets the default value for register (parameter)	
RemoveBan	Removes the blockade of communication with the Z-Wave module	
ClearFailCount	Cleans the number of failed communication attempts	
UpdateNeighbours	Triggers the action of updating and rebuilding the Z-Wave network (number of neighbouring	
	modules, method of communication with CLUZ) for a given module	
Events:		
OpBappod	Occurs when 7 Wave device is banned	

5. Technical data

Device power supply	100-265V _{ac} 50/60Hz	
Maximum power consumption	0,8W	
Maximum load voltage	265V _{ac}	
Maximum power 1 phase motor (UL 508)	1,0Hp / 265V _{ac} / channel	
Maximum current for resistive load AC1	16A / 265V _{aC} / summary, 16A / channel 1 (U), 8A / channel 2 (D)	
Insulation Low-High (230Vac) voltage	3kV	
Maximum wire cross section	2,5mm ²	
Z-wave frequency	EU: 868,4MHz	
Weight	40g	
Fixing	flush mounted	
Dimensions (H/W/D)	22/46/37mm	
Operating temperature range	0 to +45°C	

6. Wiring diagram



 The brand new device bas Standalone Mode enabled. The inputs I1, I2 control the outputs U, D.

• Low voltage G, I1, I2, 1W lines galvani-cally separated from high voltage N, L lines.

N	"Neutral" signal
L	"Line" signal
U	UP output
D	DOWN output
G	GND for 1-Wire and digital inputs
11	first digital input (potential-free)
12	second digital input (potential-free)
lW	1-Wire bus input

• The 'L' signal powers U and D outputs

7. Module Inclusion

To add the device to the Z-Wave network:

- Connect the module according to the diagram above Set your Z-Wave controller into inclusion mode.
- 2.
- Generate quickly $^{\!\!1}$ 6 pulses on 11 input. The status LED starts blinking with a period of 500ms. The status LED turns off at the end of the inclusion process.

If you are connecting this unit to a Z-Wave Controller that utilizes the S2 security protocol, you may be asked to enter the first 5 digits of Device Specific Key (DSK). You can find it on the label with QR code on the back of the unit. The device supports SmartStart function. SmartStart enabled products can be added into a Z-Wave network by scanning the Z-Wave QR Code present on the product with a controller providing SmartStart inclusion. No further action is required and the SmartStart product will be added automatically within 10 minutes of being switched on in the network vicinity. The device provides DSK representation on the product, so you can add it manually to the controller.

8. Module Exclusion

To remove the device from the 7-Wave network

- Connect the module according to the diagram above Set your Z-Wave controller into exclusion mode.
- Generate quickly¹ 6 pulses on l1 input. The status LED starts blinking with a period of 500ms.
 The status LED turns off at the end of the Exclusion process.

9. Factory Reset

To restore factory configuration

- 1. Connect the module according to the diagram above.
- Generate quickly¹ 6 pulses on I2 input. The status LED turns on.
 Generate quickly¹ 6 pulses on I1 input. The status LED turns off.

10. Standalone Mode

Standalone mode is the default operating mode of the module, in which the button (monostable) connected to the input Il causes an upward movement upon clicking or holding the button, and the button connected to the input I2 similarly causes a downward movement. This mode can be enabled / disabled using the Standalone feature of the ZWAVE_CONFIG object.

To manually enable / disable standalone mode:

- 1. Connect the module according to the diagram above
- Generate quickly ¹ 6 pulses on I2 input. The status LED turns on. Generate quickly ¹ 4 pulses on I1 input. The status LED turns off.

11. Warnings and Cautionary Statements



Before proceeding with the assembly, read the installation schematics and full instructions available at www.grenton.com.
 Failure to follow the guidelines contained in the instructions and other requirements of due care valid as a result of the nature of the equipment (device) may be dangerous to life / health, dam-age the device or installation to which it is connected, damage



 Danger to life caused by electric current! The components of the installation (individual devices) are de-signed to work in a home electrical installation or directly in its



in accordance with the instructions and / or due diligence in handling the equipment (device).
 Device power supply, permissible load or other characteristic parameters have to be in accordance with the device specification, described in particular in the "Technical data" section.
 The product is not intended for children and animals.
 If you have technical questions or comments about the device instruction for the character former a characteristic former.

operation, contact Grenton Technical Support. Answers to frequently asked questions can be found at: www.support.grenton.com.

vicinity. Incorrect connection or use may cause a fire or electric

 SNOCK.
 All work related to the installation of the device, in particular works involving interference in the electrical installation, may be performed only by a person with appropriate qualifications or licences.

 When installing the device, make sure that the power supply voltage is disconnected from the circuit in which the device is connected or near which the assembly takes place.

¹less then 200ms transition

12. CE Marking

The manufacturer declares that the device is in full compliance to the national regulations that implement the appropriate directives. The Radio Equipment Directive (RED - 2014/53/UE), the ticular, Grenton Sp. 2 o. o. declares that the device fullities the limitation of the use of specific substances in Deckines the appropriate directival in the device fullities the directive (ND 2014/35/UE) and the Directive and the Direc



13. Warranty

Warranty available at www.grenton.com/warranty.

14. Manufacturer Contact Details

Grenton Sp. z o.o. ul. Na Wierzchowinach 3 30-222 Kraków, Poland www.grenton.com