# User Manual Grenton Intercom Monitor 7" ICM-002-E-01

Grenton Intercom Monitor is a 7-inch intern video intercom with an IPS screen at a reso lution of 1024x600. It enables connection of alarm sensors and doorbell.



# 1. Technical Data


Display	7" IPS LCD, capacitive
Power supply	PoE, 12V <sub>dc</sub>
Power consumption	6W, in standby - 2.5W
Built-in camera	No
Screen resolution	1024 x 600
Body	Aluminum
Dimensions (H/W/D)	128/236/26,5mm
Installation	Wall mount, Flush mount with a special bracket

### 2. Mechanical Mounting

Before mounting the monitor, it is nec-essary to prepare a hole or recess in the wall with dimensions of 222/114/60mm (for flush mounting). It is necessary for switching of wires and installation of the monitor.


#### Wall mounting:

Attach the bracket in the outlet box ur-ing set screws and a phillips head screwdriver. Installation of the monitor on the bracket is done from top to bottom.



Flush mounting with a special bracket:






# 3. Wiring diagram

To connect monitor you will need: • An Ethernet UTP CATS or higher cable con-nected to a PoE network switch or regular switch / router (the maximum length of the UTP CATS cable segment should not exceed 100 meters, according to the IEEE 802.3 stan-

### Connecting the doorbell to the monitor:

Power supply at 12V, 2A.
 If additional inputs of the monitor are required, the appropriate number of signal cables should be routed as needed.



### Warnings and Cautionary Statements



Before proceeding with the assembly, read the installation schematics and full instructions available at www.grenton.com. Failure to follow the guidelines contained in the instructions and other requirements of due care valid as a result of the nature of the equipment (device) may be dangerous to life / health, damage the device or installation to which it is connected, damage other property or violate other applicable regu-lations. The manufacturer of the device, Gren-ton Sp. z o. o. does not bear any responsibility



Danger to life caused by electric current!
The components of the installation (individual devices) are designed to work in a home

### 5. CE Marking

The manufacturer declares that the de-vice is in full compliance with the requirements of EU legislation that includes the directives of a new approach appropriate for this equipment. In particular, centon 5p, 2 o. o. declares that the limitation of the use of specific substances the device fulfills the requirements on safety, specified by law, and that it conforms to the



# 6. Warrantv

Warranty available at: www.grenton.com/warranty

#### Manufacturer Contact Details

Grenton Sp. z o.o ul. Na Wierzchowinach 3 30-222 Kraków, Poland www.grenton.com

for the damage (property and non-property re-lated) resulting from the assembly and / or use of the equipment not in accordance with the in-structions and / or due diligence in handling the equipment (device). • Device power supply, permissible load or other characteristic parameters have to be in accordance with the device specification, de-scribed in particular in the "Technical data" sec-tion.

The product is not intended for children and

- The product or no interface animals.
   If you have technical questions or comments about the device operation, contact Grenton Technical Support.
   Answers to frequently asked questions can be found at: www.support.grenton.pl

electrical installation or directly in its vicinity. In-correct connection or use may cause a fire or electric shock. All work related to the installation of the de-vice, in particular works involving interference in the electrical installation, may be performed only by a person with appropriate qualifications or lirences

Offly up a person with appropriate quantity of licences.
When installing the device, make sure that the power supply voltage is disconnected from the circuit in which the device is connected or near which the assembly takes place.